

22 juillet 2006

00 :00	VAD2M	20	1	0	
00 :07	VAD1	20	1	1	
00 :13	VAD2	20	1	1	
00 :19	VAD1	20	1	1	
00 :26	VAD2	20	1	1	
00 :34	VAD1	18	1	1	Pb IA mal placé
00 :40	VAD1	19	1	1	
00 :47	VAD2	20	1	1	planté
00 :55	VAD2	18	1	1	
01 :03	VAD1	19	1	1	Structure (stratiforme ?) sur radar
01 :10	VAD2	19	1	1	
01 :16	VAD1	19	1	1	CAF planté/azote 0
01 :54	VADS	20	0	0	OK
01 :59	VAD1	20	1	1	PC planté
02 :06	VAD1M	20	0	0	Réactivation à l'O de la zone stratiforme
02 :13	VAD2M	19	0	0	PC planté
02 :21	VAD1M	20	0	0	OK
02 :28	VAD2M	19	0	0	OK
02 :40	VAD1M	20	0	0	OK
02 :47	VAD2M	19	0	0	OK
02 :53	VAD1M	19,5	0	0	OK
03 :00	VAD2M	20	0	0	OK
03 :07	VADS	20	0	0	OK
03 :10	VAD1M	19	0	0	OK
03 :17	VAD2M	20	0	0	Ok
03 :23	VAD1M	20	0	0	Ok
03 :30	VAD2M	20	0	0	Ok
03 :55	VAD1M	20	0	0	Ok
04 :02	VAD2M	18,5	0	0	Ok
04 :08	VADAC	20	0	0	Ok
04 :15	VADAC	20	0	0	Ok
04 :29	VADS	20	0	0	Ok
04 :49	VADS	20	0	0	Ok
05 :02	VADS	20	0	0	Ok
10 :39	VADS	20	0	0	Ok
10 :54	CAF planté remis à 15				
11 :00	VADS	18	0	0	Ok
11 :05	VADS	18	0	0	Ok
11 :06	Planté Pb du magnétron				
11 :14	VAD1M	16	0	0	Ok
11 :21	VAD2M	16	0	0	Ok
11 :28	VADS	18	0	0	Ok
11 :32	VAD1	16	1-0	1	Planté en butée Gisement
11 :38	VAD1	18-17	1	1	Planté en butée Gisement
11 :48	VADS	18	0	0	Planté en butée Gisement
11 :52	VADS	18	0	0	OK
11 :56	VAD1M	16	0	0	OK

12 :02	VAD2M	16	0	0	OK
12 :09	VAD1M	16	0	0	OK
12 :16	VAD2M	16	0	0	OK
12 :22	VAD1M	16	0	0	OK
12 :29	VAD2M	16	0	0	OK
12 :35	VAD1M	16	0	0	OK
12 :42	VAD2M	16	0	0	OK
12 :49	VAD1M	16	0	0	Pb IA
12 :50	VAD1M	16	0	0	OK
13 :02	VAD2M	16	0	0	OK
13 :09	VAD1M	16	0	0	OK
13 :15	VAD2M	16	0	0	Plantée en butée
13 :34	VADS	18	0	0	OK
13 :38	VAD1	16	0	1	OK IA instable
13 :44	VAD2	16	0	1	Planté en butée
13 :51	VAD1M	18	0	0	OK
13 :57	VAD2M	16	0	0	OK
14 :03	VAD1M	16	0	0	OK
14 :10	VAD2M	16	0	0	OK
14 :16	VAD1M	16	0	0	OK
14 :23	VAD2M	16	0	0	OK
14 :30	VAD1	16	1	1	OK
14 :37	VAD2	16	1	1	Planté en butée
14 :42	VAD2	16	1	1	Planté en butée IA instable
15 :05	VADS	19	0	0	OK
15 :08	VAD1	18	1	1	OK
15 :14	VAD2	18	1	1	OK
15 :22	VAD1M	18	0	0	Planté : magnétron à 0
15 :41	VAD1M	16,15	0	0	OK
15 :47	VAD2M	15,5	0	0	OK
15 :53	VAD1M	15,5	0	0	OK
16 :00	VAD2M	15,5	0	0	OK
16 :06	VAD1M	16	0	0	OK
16 :13	VADS	17	0	0	OK
16 :17	VAD1	16	1	1	OK IA instable + Bruit fort
16 :25	VAD2	18,16	1	1	OK
16 :32	VAD1	16	1	1	OK
16 :38	VAD2	16	1	1	Planté en butée IA instable + Bruit fort
16 :57	VADS	18	0	0	Pb magnétron tend vers 0

Changement de thyatron et de pré-modulateur

17 :47	VAD1	16-14	1-0	1	OK
17 :53	VAD2	14	0	1	Planté en butée
17 :58	VADS	20	0	0	OK
18 :02	VADS	20	0	0	OK
18 :05	VADS	20	0	0	OK
18 :09	VAD1	Planté magnétron à 0			
18 :14	VAD1	20-19	1	1	OK

18 :44	VADS	20	0	0	OK Ces 4 sequences pour l'entretien du
19 :02	VADS	20	0	0	OK magnétron
19 :28	VADS	20	0	0	OK id
19 :53	VADS	20	0	0	OK id
20 :30	VADS	20	0	0	OK
21 :00	VADS	20	0	0	OK
21 :30	VADS	20	0	0	OK
22 :00	VADS	20	0	0	OK
22 :33	VADS	20	0	0	Pb IA n'a pas accroché
23 :00	VADS	20	0	0	OK
23 :28	VADS	20	0	0	OK.