

24 juillet 2006

09 :27	VADS				Changement prémodulateur
10 :51	VADS	16	0	0	test émetteur rien Pb fin de séquence
11 :18	VADAMMA	14	0	0	OK
11 :37	VADAMMA	18	0	1	OK
16 :06	VADAMMA	20	0	0	OK
16 :10	VADAMMA	20	1	0	OK mode 200 km
16 :25	VADAMMA	18	0	1	planté en butée
16 :33	VADAMMA	19	0	0	plantée
16 :42	VADAMMA	18	0	1	OK
16 :59	VADAMMA	18	0	1	OK
17 :17	VADAMMA	18	0	1	Pb IA
17 :19	VADAMMA	18	0	1	planté en butée
17 :29	VADAMMA	18	0	1	planté en butée
17 :35	VADAMMA	18	0	1	OK
17 :52	VADAMMA	18	0	1	planté après VAD1
18 :03	VADAMMA	18	0	1	planté en butée site
18 :11	VAD1+2	18	0	0	sur console:bi; sur écran:mono; sauvgarde:mono
18 :41	VADS	20	0	0	
18 :45	VAD1	18	0	0	pc planté
19 :05	VAD1M	18	0	0	OK
19 :12	VAD2M	18	0	0	OK
19 :19	VADS	20	0	0	OK
19 :45	VADS	20	0	0	OK
20 :18	VADS	20	0	0	OK RAS
21 :33	VADS	20	0	0	OK
22 :02	VADS	20	0	0	OK
22 :33	VADS	20	0	0	OK
23 :02	VADS	20	0	0	OK
23 :30	VADS	20	0	0	OK